

# ***Stereo Cassette Deck***


---

Operating Instructions

***TC-K717ES***

# WARNING

**To prevent fire or shock hazard, do not expose the unit to rain or moisture.**



This symbol is intended to alert the user to the presence of uninsulated "dangerous voltage" within the product's enclosure that may be of sufficient magnitude to constitute a risk of electric shock to persons.



This symbol is intended to alert the user to the presence of important operating and maintenance (servicing) instructions in the literature accompanying the appliance.

## Owner's Record

The model and serial numbers are located on the rear of the unit. Record the serial number in the space provided below. Refer to them whenever you call upon your Sony dealer regarding this product.

Model No. TC-K717ES    Serial No. \_\_\_\_\_

## INFORMATION

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

## CAUTION

You are cautioned that any changes or modifications not expressly approved in this manual could void your authority to operate this equipment.

# Table of Contents

## Chapter 1 Getting Started

Features .....	3
Precautions .....	4
Unpacking .....	4
Checking the supplied accessories .....	4
Notes on installation .....	4
Checking the operating voltage .....	4
Hooking up the system .....	5
Before you begin .....	5
Hooking up an amplifier .....	5
Hooking up for tape dubbing .....	5
Identifying the parts on the front panel .....	6

## Chapter 2 Playback

Playing back .....	7
Locating a selection	
— Multi-AMS (Automatic Music Sensor) .....	8
Locating a specific playback position — Memory Play .....	9
Memorizing and locating a specific playback position .....	9
The accuracy of the digital linear counter .....	9
Playing back automatically after rewinding — Auto Play ...	10

## Chapter 3 Recording

Recording .....	10
Recording to a cassette .....	10
Protecting a recording .....	12
Adjusting the recording level .....	12
Recording FM broadcasts with the Dolby NR system .....	12
Monitoring the recorded sound .....	13
What is the Dolby HX PRO system? .....	13
Calibrating the bias current and recording level .....	13
Inserting a blank space during recording	
— Record Muting .....	15

## Chapter 4 Other Operation

Playing back and recording using a timer .....	15
--	----

## Chapter 5 Additional Information

Maintenance .....	16
Cleaning the heads and tape path .....	16
Demagnetizing the heads .....	16
Specifications .....	17
Troubleshooting guide .....	18

## Chapter 1 Getting Started

# Features

### For higher quality recording/playback

- **Dolby\* HX PRO system** for higher linearity in the tape's high-range response during recording.
- **B, C and S type Dolby\* NR systems** which reduce tape noise.
- **Bias and recording level calibration** to obtain the best recording conditions for every tape.
- **Three-head system (separate recording, playback and erasing heads)** to allow you instant monitoring of the recorded sound during recording.
- **Laseramorphous head** providing superior magnetic induction for minimal sound deterioration.
- **Quartz Locked Servo Control** for greater stability and precision in capstan rotation.
- **Sapphire Capstan Base** to enhance stability in motor rotation for clear sound reproduction.
- **Closed Loop Dual Capstan** for improved stability of tape running at tape heads.
- **Ceramic cassette holder** for improved stability of tape running during playback and recording.

### For your convenience

- **Multi-AMS and Memory Play functions** for easy access to specific selections.
- **Time-specified playback and recording** using an optional timer.

### For easier operation

- **Easy-to-read digital linear counter** showing the elapsed recording or playing time.

\* Dolby noise reduction and HX Pro headroom extension manufactured under license from Dolby Laboratories Licensing Corporation. HX Pro originated by Bang & Olufsen.

"DOLBY", the double-D symbol  and "HX PRO" are trademarks of Dolby Laboratories Licensing Corporation.

# Precautions

## On safety

- Should any solid object or liquid fall into the cabinet, unplug the unit and have it checked by qualified personnel before operating it any further.
- Unplug the unit from the wall outlet (mains) if it will not be used for a long time. To disconnect the cord, pull it out by grasping the plug. Never pull the cord itself.

## On operation

- When the unit is not used, turn the power off to conserve energy and to extend the useful life of your unit.
- Because of a safety mechanism, the function buttons will not operate if the cassette holder is not completely closed, if there is no cassette in the cassette holder, or if a cassette has been incorrectly inserted into the cassette holder.

## On head cleaning

The head and tape path should be cleaned after every ten hours of operation. Dirty heads and a dirty tape path may cause:

- loss of high-frequency response
- loss of sound volume
- sound drop-out

## On cleaning the cabinet

Clean the cabinet, panel and controls with a soft cloth slightly moistened with a mild detergent solution.

Do not use any type of abrasive pad, scouring powder or solvents such as alcohol or benzene.

If you have any questions or problems concerning your unit, please contact your nearest Sony dealer.

## For the customers in the U.S.A.

For detailed safety precautions, see the leaflet "IMPORTANT SAFEGUARDS".

# Unpacking

## Checking the Supplied Accessories

Make sure that the following accessories are included with your unit.

- Audio connecting cords (2)

## Notes on Installation

- Place the unit with the front panel facing you in a location with adequate air circulation to prevent overheating of the unit.
- Do not place the unit:
  - near heat sources such as radiators or air ducts.
  - in places subject to direct sunlight, excessive dust, mechanical vibration or shock.
  - in an inclined position.
  - on a rug or other soft surfaces that would block the ventilation holes on the bottom of the unit.

## Do not throw away the carton and the packing material

They will come in handy when transporting the unit or shipping it for servicing.


## Checking the Operating Voltage

- Operate the unit only on 120 V AC, 60Hz (U.S.A. model) or 240 V AC, 50 Hz (Australia model).
- Before connecting the unit to an AC (socket) outlet, be sure that the operating voltage of your unit is identical with that of your local power supply.


# Hooking Up the System

## Before You Begin


- Turn off the power to all equipment to be connected before making any connection.
- Note that the red plug of the supplied connecting cord is for right-channel (R) connection and the white plug for left-channel (L) connection.
- The connecting cords should be fully inserted into the jacks. A loose connection may cause hum pickup.



## Hooking Up an Amplifier




## Hooking Up for Tape Dubbing



# Identifying the Parts on the Front Panel

## \* Remote control sensor





For details, refer to the page number(s) indicated in parentheses.

- 1 POWER switch
- 2 TIMER switch (page 15)
- 3 Peak level meter (page 12)
- 4 Tape TYPE indicator
- 5 Linear counter (page 9)
- 6 MEMORY indicator
- 7 COUNTER buttons  
RESET button (page 9)  
MEMORY button (pages 9 and 10)
- 8 Cassette holder
- 9 DOLBY NR (noise reduction) switch (pages 7 and 10)
- 10 MPX FILTER button (page 12)
- 11 BIAS control (pages 13 and 14)
- 12 REC (recording) LEVEL control for calibration (pages 13 and 14)
- 13 REC (recording) LEVEL control (pages 11 and 12)
- 14 BALANCE control (page 11)
- 15 PHONE (headphones) LEVEL control (page 7)
- 16 HEADPHONES jack (stereo phone jack) (page 7)
- 17 CALIBRATION button (pages 13 and 14)
- 18 MONITOR button (page 13)

- 19 OPEN/CLOSE button
- 20 Tape operation buttons
  - (stop) button
  - ◀◀ (rewind) (Multi-AMS\*\*) button
  - ▶ (play) button
  - ▶▶ (fast-forward) (Multi-AMS\*\*) button
  - || PAUSE button
  - REC MUTE (record muting) button (page 15)
  - REC (recording) button

## \*Remote control sensor


You can remotely control this cassette deck with:

- A remote commander that came with a Sony amplifier or receiver if it has the  mark and cassette deck control capability.
- An optional Sony remote commander with the  mark and cassette deck control capability.

\*\* AMS is an abbreviation for Automatic Music Sensor.


# Playing Back

Follow the procedure below to play back a cassette.





**1** Turn on the amplifier and select the tape function.


**2** Insert a cassette with the side to be played facing outward.



**3** Set DOLBY NR to the same position that was used when the cassette was recorded.






**4** Press  to start playback.



To stop playback, press the  button.

To stop playback momentarily, press the  button.

To restart playback, press the  or  button.

To fastwind a tape rightward, press the  button in stop mode.

To fastwind the tape leftward, press the  button in stop mode.





## Set the TIMER switch to OFF

Otherwise, recording or playback will start automatically when the power is turned on.



## Specifying the tape type is unnecessary

The deck has an automatic tape type detection system.

## To start operations while the cassette holder is open

Operations may be started while the cassette holder is open. For example, when the  button is pressed while the cassette holder is open, the cassette holder will close and playback will start. Similarly, pressing the , , or  buttons while the cassette holder is open will close the cassette holder and start the respective operation.

## To begin recording during playback

While holding down the  button, press the  button. The unit immediately begins recording without stopping the tape. This function is useful when editing previously recorded material.

## For headphone listening

Insert the headphone plug to the HEADPHONES jack. The listening level can be controlled with the PHONE LEVEL control.

## Selecting TAPE mode with the MONITOR button is unnecessary

The unit automatically enters TAPE mode and the TAPE indicator lights up.

## What is the Dolby NR system?

The Dolby NR (noise reduction) system reduces tape hiss noise in low-level, high-frequency signals by boosting the signals during recording and lowering them during playback.


The Dolby S NR system provides the highest reduction in tape hiss noise in both low and high frequencies.

## Note

The Dolby HX PRO system works only during recording, not during playback.

# Locating a Selection — Multi-AMS (Automatic Music Sensor)

Through its ability to detect the blank space between selections, the Multi-AMS function allows you to skip up to 30 selections while fast forwarding or reversing to the beginning of a specific selection.




During playback, press ►► or ◄◄ as many times as the number of selections to be skipped.

For selections after the current one: Press ►► the required number of times.

For selections before the current one: Press ◄◄ the required number of times\*.

\* Pressing ◄◄ once locates the beginning of the current selection.

↓ : Beginning of the selection



• Each time the unit detects a blank space, the indicated Multi-AMS number decreases by one.

• The ►► indicator flashes during Multi-AMS operation.

• When the beginning of the specified selection is reached, the counter indication appears again and playback automatically restarts.



## Changing the indicated number of selections to be skipped

Press the ◄◄ or ►► button at any time, even during Multi-AMS operation.

## The Multi-AMS number may change as you are setting it

due to the detection of blank spaces as the unit begins to fastwind.

## The Multi-AMS may fail to detect the start of a selection in the following cases:

- If you press the ►► button immediately before the selection or the ◄◄ button immediately after the start of the selection.
- If there is noise in the space before the selection.
- If the space before the selection is less than four seconds long.

## The Multi-AMS will treat the following as blanks:


- A long pause in the music
- A passage of low frequencies or very low volume
- A gradual increase or decrease in volume





# Locating a Specific Playback Position — Memory Play

## Memorizing and Locating a Specific Playback Position



The Memory Play function allows you to use the counter to record a specific position on a cassette for fast relocation and automatic playback later.




- 1 Press MEMORY to turn on the Memory Play function.**



- 2 Press RESET to reset the counter at the position to be memorized.**  
The position is memorized.



- 3 While holding down ▷, press ◀◀ to return to the memorized position.**



## Returning to the memorized position while the unit is stopped — Memory Stop

If you press only the ◀◀ button when the MEMORY indicator is on and the unit is stopped, the tape rewinds and then stops when the counter reaches 0.00.

Be sure that the unit is stopped before turning the Memory Stop function on, otherwise the Multi-AMS function will operate.

## To turn off the Memory Play function

Press the MEMORY button, so that the MEMORY indicator disappears.

## Note on Memory Play/Stop

The tape actually rewinds to slightly short of 0.00.

## Do not turn off the power while using the counter


Turning the power off, then on again resets the counter to 0.00.

## The Accuracy of the Digital Linear Counter


Since the counter is not a digital clock, it will differ from the actual elapsed playback or recording time by a few minutes, depending on such factors as tape length and hub size.

## Playing Back Automatically After Rewinding — Auto Play


The Auto Play function automatically starts playing back a cassette after fastwinding it to the beginning.



- 1 Make sure the MEMORY indicator is off.**  
If not, press MEMORY.




- 2 While holding down  $\blacktriangleright$ , press  $\blacktriangleleft$ .**




## Recording

### Recording to a Cassette


Follow the procedure below to record a source on a cassette.



- 1 Insert a cassette with the side to be recorded facing outward.**  
(Refer to pages 13 to 14 to calibrate the bias current and recording level if desired.)



- 2 Set DOLBY NR.**



- 3 Press  $\bullet$  to enter the recording pause mode.**



- 4 Play the program source to be recorded.**

- 5** Turn **REC LEVEL** to adjust the recording level.



See "Adjusting the Recording Level" on page 12.

- 6** Turn **BALANCE** to adjust the balance.



- 7** Restart the program source, if required.

- 8** Press **II** or **▷** to start recording.



or



**To stop recording**  
Press the **■** button.

**If playback starts instead of recording when you press ●**

The record-protect tab for that side has been removed. To record on this cassette, cover the hole with plastic tape. (See "Protecting a Recording" on page 12.)

**Set the TIMER switch to OFF**

Otherwise, recording or playback will start automatically when the power is turned on.

**Selecting MONITOR mode is unnecessary**

The unit automatically enters source mode and the SOURCE indicator lights up. If you wish to monitor the recorded sound, press the MONITOR button to select TAPE mode.

**To start recording while the cassette holder is open**

If you press the ● button while the cassette holder is open, the holder will close automatically and the unit will switch to recording pause mode. This function allows you to start recording at a moment's notice.

**Checking the recording time on a tape**

To check the remaining recording time on a tape:

- 1 Press the RESET button to reset the counter to 0.00.
- 2 Press the ►► button to advance the tape to its end. The number on the counter shows the approximate recording time.


To check the total recording time of a tape, first rewind the tape to its beginning, then follow the same steps as above. (See "The Accuracy of the Digital Linear Counter" on page 9.)

# Recording

## Protecting a Recording

### To protect a recording on side A or B

Break out the respective tab.




### To record on a cassette that is protected

Cover the respective hole with tape.



### When using Type II or Type IV cassettes

Be careful not to cover the detector slots which are necessary for automatic tape-type detection.



## Cassette care

- Avoid touching the tape surface of a cassette to prevent contamination of the heads by dirt, dust, or oil on the skin.
- Keep cassettes away from equipment with magnets, such as speakers and amplifiers, as erasure or distortion on the recorded tape could occur.
- Do not expose cassettes to direct sunlight, extremely cold temperatures or moisture.

### Note on cassettes longer than 90 minutes

We do not recommend the use of cassettes longer than 90 minutes except for long continuous playback.


## Adjusting the Recording Level

The proper recording level, which differs according to the tape type, is indicated on the peak level meters for each tape type.

Adjust the REC LEVEL control as high as possible without exceeding the recommended range for the inserted tape.

### Peak level meter recording by tape type

Recommended maximum peak level meter readings.



### Tips on recording level adjustment

Setting the recording level too low will produce a hissing sound, while setting it too high will produce distortion. Generally, the proper recording level for high and low frequencies is lower than that for middle frequencies. When recording program sources with many high and low frequencies, set the level to a relatively low position, then make adjustments according to the recording results.

## Recording FM Broadcasts With the Dolby NR System

If your tuner does not have an MPX filter, or, if equipped, the filter is not working effectively, set the MPX FILTER button to ON (the FILTER indicator appears) when recording FM broadcasts with the Dolby NR system. The MPX filter eliminates remnants of the 19-kHz stereo carrier and 38-kHz subcarrier signals which may impair the operation of the Dolby NR system. Be sure to turn on the DOLBY NR switch since the MPX filter will not function otherwise.

## Calibrating the Bias Current and Recording Level

### Monitoring the Recorded Sound


As this unit has three separate heads for recording, playback and erasure, you can check the quality of a recorded sound by comparing it with the input source signal.

To listen to the input source signal, press the MONITOR button to turn on the SOURCE indicator.

To listen to the sound recorded on the tape, press the MONITOR button to turn on the TAPE indicator.

### Comparing the recorded sound with the sound source


While recording, use this monitoring function to check that there is no distortion due to excessive level settings or sound degradation due to head contamination.



### What Is the Dolby HX PRO System?


The Dolby HX PRO system provides precise bias control during recording to reduce distortion and improve linearity in the high-frequency range. The result is recorded sound that is highly faithful to the original. Since the HX PRO system operates only during recording, the same high-quality sound is produced even during playback on other tape decks. The HX PRO system is independent from the Dolby NR system and is unaffected by the Dolby NR setting.

Although the ATS (Automatic Tape Selection) system in your unit sets the appropriate equalization characteristics and bias current for each tape type, you may be able to obtain even better results by doing the bias current and recording level calibration function described below.



### Bias calibration

Choosing the proper bias current for a tape ensures minimum distortion and flat frequency response. Lowering the bias current boosts high-frequency response, but also results in higher distortion. Raising the bias, on the other hand, reduces distortion, but also dampens high-frequency response. You thus obtain proper bias when the bias current and high-frequency response are well balanced.




- By changing the bias, you can tailor the response to your liking, for example by slightly emphasizing the upper or lower end.
- The frequency response of metal tape is much less affected by changes in the bias current than other tape types, and in some cases is unaffected. The adjustment range of this deck (about  $\pm 20\%$ ) may therefore not be wide enough to allow adjustment for all tapes.

### Recording level calibration


Even when the recording level is adjusted correctly, a tape with low sensitivity will result in a low playback level. The REC LEVEL calibration control allows you to compensate for sensitivity differences among tapes to equalize both recording and playback levels. This is especially important when using the Dolby NR system, since the system is most effective when recording and playback levels are the same.

# Calibrating the Bias Current and Recording Level

Follow the procedure below to calibrate the bias current and recording level.



- 1 Insert a cassette with the side to be recorded facing outward.




- 2 Press CALIBRATION.



The peak level meters for adjusting the bias and recording level appear in the display window.

- 3 Press ●, then II or ► to turn on the recording test tones.




## Notes


- You cannot monitor the sound during the calibration operation.
- It takes 2 to 3 seconds for the test tone level to stabilize.

- 4 Adjust BIAS until both meters indicate equal playback levels.


A high reading on the upper meter indicates a low bias current.



A low reading on the upper meter indicates a high bias current.




An equal reading on both meters indicates the proper bias current condition.



- 5 Adjust REC LEVEL for calibration until both meters reach the recommended level.




Recommended level




The bias current is now properly adjusted and the tape sensitivity compensation has been set. Press ■, then press CALIBRATION to turn the calibration function off (the display returns to normal). Rewind the tape and start the actual recording.

## Inserting a Blank Space During Recording — Record Muting

The Record Muting function allows you to insert a four-second blank between selections to enable proper Multi-AMS operation (see page 8), or to replace unwanted recorded material with a blank of any length.



### 1 While recording, press and release **O**.



The REC indicator starts flashing. During this time, no incoming signals are recorded on the tape.

After four seconds, the **||** indicator lights up and the unit enters recording pause mode.

### 2 Press **||** to resume recording.




#### To create a blank longer than four seconds

Press the **O** button for the specified length of time. After four seconds, the REC indicator flashes at a faster rate. When you release the **O** button, the **||** indicator lights up and the unit goes into recording pause mode.

Press the **||** button to resume recording.

## Chapter 4 Other Operation Playing Back and Recording Using a Timer

By using an optional timer, you can record or play back at a preset time.



### 1 Prepare the tape deck for playback or recording.

For playback	Follow steps 1 through 3 on page 7.
For recording	Follow steps 1 through 6 on pages 10 and 11.

After completing the preparations, press **■** to change the tape deck to stop mode. Make sure to close the holder completely.

### 2 Set the timer.

Power to the tape deck turns off.

### 3 Set **TIMER** to **PLAY** or **REC**.

Playback or recording will start at the preset time.

#### Note

After timer-activated recording has completed, set the **TIMER** switch on the tape deck to **OFF**. If you leave the **TIMER** switch at **REC**, the unit will automatically start recording the next time you turn the power on, and recorded material may be erased.

#### Keep the **POWER** switch on the unit on

When you set the timer, the power to the tape deck turns off. You must, however, leave the **POWER** switch on to enable timer-activated operation.

# Maintenance


## Cleaning the Heads and Tape Path

Clean all surfaces over which the tape travels after every ten hours of operation to guard against:

- low-quality sound
- a decrease in sound level
- excessive wow, flutter or drop-out
- incomplete erasure
- impairment of recording function

To obtain high-quality recorded sound, we recommend cleaning before every recording.

- 1 With the unit turned off, hold down  $\triangle$  and press the POWER switch. This causes the holder to open, the heads to rise and the pinch rollers to rotate.**
- 2 Wipe the heads, the pinch rollers and the capstans with a cotton swab slightly moistened with alcohol or a commercially available cleaning fluid for tape decks.**  
Clean the entire surface of the pinch rollers and capstans while they are rotating, making sure that the cotton swab does not get caught in the mechanism.
- 3 When completed, press  $\triangle$  again.**



Do not insert a cassette until the cleaned areas are completely dry.

## Demagnetizing the Heads

After 20 to 30 hours of use, or when you notice hiss and/or loss of high frequencies, the residual magnetism built up on the heads should be removed.

- 1 With the unit turned off, hold down  $\triangle$  and press the POWER button to open the holder. Confirm that the heads have risen, then press the POWER button again.**
- 2 Demagnetize the heads with any commercially available demagnetizer.**
- 3 Turn the power on.**  
The cassette holder closes.

Refer to the instruction manual of the demagnetizer for detailed instructions.



# Specifications

Recording system	4-track 2-channel stereo
Fast winding time	Approx. 90 sec. (with Sony C-60 cassette)
Bias	AC bias
Heads	Erasing head × 1 (S&F head) Recording head × 1 (SD head) Playback head × 1 (LA head)
Motors	Capstan motor × 1 (DC servo motor) Reel motor × 1 (DC motor) Assist (mechanism drive) motor × 1 (DC motor)

Signal-to-noise ratio (at peak level and weighted)

Cassette (Dolby NR off)	Type IV	Type II	Type I
	61 dB	59 dB	57 dB

S/N ratio improvement (approximate values)

With Dolby B NR on : 5 dB at 1 kHz; 10 dB at 5 kHz

With Dolby C NR on : 15 dB at 500 Hz; 20 dB at 1 kHz

With Dolby S NR on : 10 dB at 100 Hz; 24 dB at 1 kHz

Harmonic distortion	0.4% (with Type I, 160 nWb/m, 315 Hz, 3rd H.D.) 1.5% (with Type IV, 250 nWb/m, 315 Hz, 3rd H.D.)
---------------------	---

Frequency response (Dolby NR off)

Type IV cassette	20 - 21,000 Hz (±3 dB, IEC) 20 - 16,000 Hz [±3 dB (-4dB recording)]
Type II cassette	20 - 19,000 Hz (±3 dB, IEC)
Type I cassette	20 - 17,000 Hz (±3 dB, IEC)

Type IV : Sony Type IV (METAL)

Type II : Sony Type II (HIGH)

Type I : Sony Type I (NORMAL)

Wow and flutter	±0.06% W.Peak (IEC) 0.04% W.RMS (NAB) ±0.11% W.Peak (DIN)
-----------------	---

Inputs

Line inputs (phono jacks)	Sensitivity	0.16 V
	Input impedance	47 k ohms

Outputs

Line outputs (phono jacks)	Rated output level	0.5 V at a load impedance of 47 k ohms
	Load impedance	Over 10 k ohms
Headphones (stereo phone jack)	Output level	0 - 3 mW at a load impedance of 32 ohms

## General

Power requirements	Model for U.S.A.: 120 V AC, 60 Hz Model for Australia: 240 V AC, 50 Hz
Power consumption	21 W
Dimensions	Approx. 430 × 123 × 306 mm (w/h/d) (17 × 4 <sup>7</sup> / <sub>8</sub> × 12 <sup>1</sup> / <sub>8</sub> inches) including projecting parts and controls
Mass	Approx. 4.9 kg (10 lbs 13 oz)

## Supplied accessories

Audio connecting cords (2)

## Optional accessory

Wireless remote commander RM-J701

Design and specifications are subject to change without notice.

# Troubleshooting Guide

The following trouble checks will help you correct the most common problems encountered with your tape deck. Should any problems persist after you have made these checks, consult your nearest Sony dealer.






Before proceeding with these trouble checks, verify that:

- The power cord is firmly connected.
- The amplifier connections are firmly made.
- The heads, capstans and pinch rollers are clean.
- The amplifier controls and switches are correctly set.

## Function Buttons and Tape Transport Problems

Symptom	Cause	Remedy
The function buttons do not work.	The cassette holder is not fully closed.	Close the holder completely.
	The cassette is not properly inserted.	Insert the cassette correctly.
	You press the button immediately after turning on the power.	Wait until the III indicator stops flashing.
Playback or recording begins when the power is turned on.	The TIMER switch is not set to OFF.	Set the TIMER switch to OFF.
The ● button does not work.	There is no cassette in the holder.	Insert a cassette.
	The record-protect tab has been removed from the cassette.	Cover the hole with tape (page 12).
The automatic shut-off mechanism operates before the end of the tape.	The tape is slack.	Take up the tape slack.
	The cassette shell is deformed.	Use another cassette.
	The Memory Play function is on.	Press the MEMORY button to turn off the function.
Excessively loud tape transport noise during fast winding.	This noise is caused by the cassette and is not a mechanical problem.	—
The cassette holder will not close.	There has been a power failure or the power cord has been disconnected while the cassette holder is open.	Reconnect the power.
The ⏮ button does not function.	There has been a power failure or the power cord has been disconnected.	Reconnect the power.

## Recording and Playback Problems

Symptom	Cause	Remedy
Recording or playback cannot be made or there is a decrease in sound level.	The heads are either dirty or magnetized.	Clean or demagnetize the heads (page 16).
	Improper connection.	Make connections properly (page 5).
	Improper setting of the amplifier controls.	Set the amplifier controls to the appropriate positions.
Excessive wow, flutter or drop-out.	The head, capstan or pinch roller is dirty.	Clean in accordance with instructions on page 16.
Incomplete erasure.	The erasing head is dirty.	Clean the erasing head (page 16).
Increased noise or poor reproduction in high frequencies.	The heads are magnetized.	Demagnetize the heads (page 16).
Unbalanced tone in high frequencies.	Improper setting of the DOLBY NR switch.	During playing back, set the switch to the same position used in recording.
	The unit is placed near a television set.	Move the unit away from the television set.
The specified selection cannot be located even when Multi-AMS is on.	There is noise in the space before the selection. The space before the selection is less than four seconds long.	Rerecord the tape if you can, and insert a blank space of four seconds before the selection using the  button (page 15).
	The  ( or  ) button was pressed immediately before the beginning of the following selection.	
Playback begins in the middle of the selection when Multi-AMS is on.	The selection contains one of the following: — a long pause — a passage of low frequencies or very low volume — a gradual increase or decrease in volume.	While the tape is playing, press the  or  button again.

## Noise

Symptom	Cause	Remedy
Hum noise.	The unit is stacked on or under the amplifier.	Separate the unit.
Noise is recorded.	The recording was made near equipment such as a television set or a color monitor, and interference has affected the recording on the tape and the Dolby NR system.	Move the unit away from the television set or color monitor.